




Constellation-X SXT optics tasks at MSFC



Steve O'Dell, Bill Jones, & Jeff McCracken
NASA Marshall Space Flight Center



MSFC FY2004 SXT optics tasks

❑ X-ray test optics.

- Perform x-ray testing in MSFC 100-m facility.
 - Have completed 6-DOF optics mount and preparations for x-ray testing.
 - Are completing rehearsal (“dry run”) with OAP 2 unit.
 - Will perform x-ray testing and analysis of development units.

❑ Support segmented-mirror replication experiments at GSFC.

- Process 0.5-m cylindrical metal mandrels made by Zeiss.
 - Are re-processing (cleaning and gold coating) mandrel 50Z1 to GSFC.
 - Will continue re-processing 50Z1, then 50Z2 for final mirrors for EU.



❑ Procure and accept meter-class precision segment mandrels.

- Procure Zerodur™ segment mandrels for GSFC mirror development.
 - Have received all segment mandrels (Type A, B & C) from Zeiss.
- Conduct acceptance inspection and metrology on received mandrels.
 - Completed metrology mount and modifications for segment mandrels.
 - Performed coordinate, long-trace, surface-texture metrology on mandrel A.
 - Analysis of mandrel A metrology ongoing; mandrels B & C in queue




Support for SXT development



X-RAY TESTING



MANDREL METROLOGY



CLEANING & COATING







❑ OAP 2 Rehearsal.

- End-to-end system checkout
 - Stray Light Facility (SLF)
 - X-ray sources
 - 6 Degree-of-Freedom (6-DoF) optics mount
 - X-ray detector (2048 x 2048 cooled CCD)
 - Optic and thermal control enclosure
 - Test procedures
- Generally successful checkout
 - 6-DoF mount, thermal enclosure operated in vacuum
 - CCD operated with no evidence of electrical interference between 6-DoF motors and thermal enclosure heaters
 - No light leaks in facility (would “fog” CCD images)
- Identified improvements
 - Brakes for 6-DoF mount actuator motors
 - Improved software for 6-DoF mount






Loading 6 Degree-of-Freedom Mount into SLF








OAP 2 & Thermal Enclosure Preparation





OAP 2 & Thermal Enclosure in SLF





X-ray Source & CCD Detector

